MOSI - 00097 - A005

INSTRUCTIONS-HEADER MTG.

+.002 000 Dare 8 / 16/ 85

OLE DIA ECIMAL.

Please note the following Option Switch Settings for the SAC-I game reflect the state of the game as of Movember 12, 1984. The option switches are located at 61 and H1 of the SAC-I board, at the top-far end of the board as it sits in the SAC-I Game Cabinet facing from the front.

RELEPSE 8/16/85

FURO-HAT TRICK\*\*
Part No. 020-8012-01-0A
Option Switch Settings

19

Right Coin Mech x 6	OFF	OFF	10.4					
Right Coin Mech x 5	OFF.	NO						
Right Coin Mech x 4	NO	OFF	- 1					
* Right Coin Mech x 1	NO	NO	1					
Left Coin Mech x 2	140	MU				ale		
* Left Coin Mech x 1			OFF	atang atang S	* 4 1			
5 Colns Adds 3 Bonus Colns		4.0	NO					
5 Coins Adds 2 Bonus Coins				140	OFF.	170		
5 Coins Adds 1 Bonus Coin				OFF	OFF	NO		
4 Coins Adds 2 Bonus Coins				OFF	NO	OFF		
4 Coins Adds 1 Bonus Coin				OFF	NO	NO		
3 Coins Adds 1 Bonus Coin				NO	OFF	OEE .		- 1
2 Coins Adds 1 Bonus Coin				NO	OFF	NO		
* No Bonus Coins				NO	NO	OFF		
2 COINS/1 Credit				NO	NO	NO		
1 COIN/2 Credits							OFF	OEE :
* 1 COIN/1 Credit			-				OFF	NO
FREE PLAY							NO	OFF
EDEE DI VA							NO	NO
			400					
	8	Z	9	2	F	2	7	T
No. of the last of		IH						
L'american de la company de la								
* Attract Sounds	NO	XX	XX	XX				-4
No Attract sounds	OFF	XX	XX	XX				
1 Player/Credit		XX	XX	XX	NO			
* 1 or 2 Players/Credit		XX	XX	XX	OFF	. 1		
Geme Time - 1:15		XX	XX	XX		NO	NO	NO
Geme Time - 1:30		XX	XX	XX		NO	NO	OFF
Ceme Time - 1:45		XX	XX	XX		NO	OFF	NO
* Geme Time - 2:00		XX	XX	XX		NO	OFF	1±0
Geme Time - 2:15	2.42	XX	XX	XX		OFF	NO	NO
Game Time - 2:30		XX	XX	XX		OFF	NO	110 0FF
Geme Time - SP:S		XX	XX	XX		OFF	OFF	NO
Geme Time - 3:00		XX	XX	XX		OFF	OFF	OFF
	7_1	,						3.20
	8	Z	9	3	F	Ξ	7	T
								•